

IC-ID31A UHF Digital Transceiver

Battery Packs and Cases

BP271 7.4V/1150 mAh (min) 1200mAh (typ) Li-Ion battery. Operating time 4.5 hrs in FM and DV mode (typical operation 1:1:8 duty cycle) same as supplied
BP272 7.4V/1880 mAh (min) 2000 mAh (typ) Li-Ion battery. Operating time: 8 hours in FM mode and 7.5 hours in DV mode (typical operation in 1:1:8 duty cycle)
BP273 Battery case (LR6 (AA) x 3)

Battery Chargers

BC167S Wall charger (BC167SA/SD/SV version available) provides 12V/500mA output. Charges the BP271 in 6 hours (aprox). Same as supplied
BC202 Rapid desktop charger. Charges the BP271 in 2 hours (aprox).
+ BC123S AC adapter (BC123SA/SE versions available). AC adapter is supplied with the BC202, depending on version

Power Supply Cables

CP19R Cigarette lighter cable with DC-DC converter
CP12L Cigarette lighter cable with noise filter
OPC245L/LR DC power cable. For use of the transceiver with external power supply (12V DC required)

Cloning Software and Cable

CS-31 Cloning software for ID-31A/E (supplied with ID31A/E) Allows memory channels and other settings from a PC
OPC2218LU Cloning cable (USB type)

Speaker Microphones and Ear Phone

HM75LS Remote control speaker microphone with slim L-type connection. Allows you to remotely select operating channel according to programming
HM186LS Compact type speaker microphone with slim L-type connector
HM153LS Durable type earphone microphone with slim L-type connector
HM66LS Light type earphone microphone with slim L-type connector
SP13 Earphone. OPC2114 is required
OPC2114 Slim L-type plug adapter cable (regular 2-pin connections to slim L-type connectors)

Headsets

HS94 Earphone-headset (use with OPC2006LS)
HS95 Behind the head headset (use with OPC2006LS)
HS97 Throat microphone (use with OPC2006LS)
OPC2006LS Plug adapter cable. OPC2006LS is required when using the HS94, HS95, and HS97

Belt Clip

MB127 Alligator type. Same as supplied

Carrying Case

LC178 Helps protect the transceiver from scratches

Antennas and Antenna Adapter

FAS270C UHF antenna. Same as supplied
AD98SMA SMA-BNC connector adapter

CI-V Level Converter

CT17 For remote transceiver control from a PC equipped with an RS-232C port